

SOUNDTUBE[®]

by  MSE AUDIO[®]



IPD-HUB 2 | OWNER'S MANUAL

Rev 07.07.2020

IPD-HUB 2 | OWNER'S MANUAL

Please read the following instructions carefully before installing your SoundTube® amplifier. If you have any questions regarding installation that are not answered in the following directions, please contact your local sound contractor or the SoundTube®/MSE Audio® technical support team. Contact information can be found on the back of the manual.

Important Safety Instructions

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Only use the attachments/accessories specified by the manufacturer.
- 10) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 11) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Consignes de Sécurité Importantes

- 1) Lisez ces instructions.
- 2) Conservez ces instructions.
- 3) Respectez tous les avertissements.
- 4) Suivez toutes les instructions.
- 5) Ne pas utiliser cet appareil près de l'eau.
- 6) Nettoyer seulement avec un chiffon sec.
- 7) Ne pas bloquer les ouvertures de ventilation. Installer conformément aux instructions du fabricant.
- 8) Ne pas installer près de sources de chaleur telles que des radiateurs, registres de chaleur, poêles ou autres appareils (incluant les amplicateurs) qui produisent de la chaleur.
- 9) Utiliser uniquement les xations / accessoires spéciés par le fabricant.
- 10) Débranchez cet appareil pendant les orages ou si inutilisé pendant de longues périodes de temps.
- 11) Conez toute réparation à un personnel qualié. Une réparation est nécessaire lorsque l'appareil a été endommagé de quelque façon que ce cordon d'alimentation ou la che est endommagé, l'appareil a été exposé à la pluie ou à l'humidité, s'il ne fonctionne pas normalement ou s'il est tombé.

Included in the Box


- 1 - IPD-Hub 2 Amplifier
- 1 - 4-pin Euroblock jack connector
- 1 - 2-pin Euroblock connector




Installation Instructions: IPD-Hub 2 Amplifier




1. Unpack
Unpack the amplifier.




2. Mount Amp
Mount the amp in the desired location using the side mounting rails.




3. Connect Wires
Connect the speaker wires to the 4-pin Euroblock. Connect either 1 - 8 ohm speaker or 2 - 16 ohm speakers to each channel.




4. Connect Port
Connect an RVC and Axiom device to the yellow Axiom Port.




5A. Power Amp: Option A
Decide how the amp will be powered. There are 3 options. Choose only one.
Option A: With STNet 40W PoE, PoE+ or PoE through the Ethernet cable.



5B. Power Amp: Option B
Option B: With an optional 24V 2A power supply with 5.5mm x 2.1mm center + male Barrel connector.




5C. Power Amp: Option C
Option C: With an optional 24V 2A power supply connected to the 2-pin Euroblock.



6. Done
Enjoy your newly installed IPD-Hub 2 amplifier!

Additional Instructions



7. Reset
To bring the Hub 2 back to factory default settings, hold the reset button for 5 seconds and release.

For more Dante® products, view the SoundTube® STNet® series
online, or through an authorized dealer or distributor.

