

AC-AEX-KIT

Quick Start Guide

The AC-AEX-KIT is a basic solution for extending audio signals up to multichannel 5.1. Featuring Bidirectional POC and capable of sending both analog and digital up to 100 meters over traditional cat 5e and up to 130 meters over shielded cat 5e. The AEX also has a Dual Play function, allowing simultaneous playback on both the analog and digital output, regardless of input.

AEX CONNECTION DIAGRAM



Setup

1. Connect the audio Input source to desired input on the AC-AEX-T.
2. Set the Input Source switch to the desired input on the AC-AEX-T.
3. Connect the AC-AEX-T to the AC-AEX-R using Cat 5e or better.
4. Connect the AC-AEX-R to PC or similar device using the desired audio output(s).
5. Connect power to preferred device to provide power to both devices.

Troubleshooting

- No Audio – Ensure Desired Input is selected.
- No Audio – Ensure multichannel audio does not exceed Dolby Digital 5.1.
- No POC – Try powering at other device. Ensure the Category run has not been damaged.
- No POC – Ensure distance does not exceed Cat Capabilities (100M UTP/130M STP).



AEX SIMPLE CONNECTION DIAGRAM

