

12G SDI Optical Fiber Extender

FTSM



Thank you for purchasing FTSM

FTSM, Supports video pathological patterns for SD, HD, 3G, 6G and 12G SDI. FTSM transmits very high speed 12G-SDI signals over long distances through Optical Fiber Cable (1-Channel) And it can transmit a maximum 4K Ultra HD resolution.

12G SDI Optical Fiber Extender

FTSM



Thank you for purchasing FTSM

FTSM, Supports video pathological patterns for SD, HD, 3G, 6G and 12G SDI. FTSM transmits very high speed 12G-SDI signals over long distances through Optical Fiber Cable (1-Channel) And it can transmit a maximum 4K Ultra HD resolution.

Technical and Sales Support

KOREA HQ

OPHIT CO., LTD.

3F Suntechnovil, 5-27 Mangpo-Dong, Youngtong-Gu, Suwon-City,
Kyunggi-Do, Korea (16681)

Tel: + 82 (0)31 695 5543

Fax: + 82 (0)31 695 5545

E-Mail

jhchoi35@ophit.com

Regional Office

USA

Foreseeson Custom Display

2210E, Winston Road Anaheim,
CA 92806 USA

Tel: +1-714 300 0540

Fax : +1-714 300 0546

E-mail: jhan@foreseesonusa.com

UK

Foreseeson UK Ltd

Unit 71 Barwell Business Park, Leatherhead road,
Chessington, Surrey, KT9 2NY UK

Tel : +44 (0) 203 588 1607

Fax : +44 (0) 208 546 3931

E-mail: leon.bang@fsnmed.eu

Europe

Foreseeson GmbH

Industriestrasse 38a
63150 Heusenstamm, Germany

TEL: +49(0)6104-643980

FAX: +49(0)6104-64398-11

E-mail: christian.elfert@fsnmed.eu

www.ophit.com



Technical and Sales Support

KOREA HQ

OPHIT CO., LTD.

3F Suntechnovil, 5-27 Mangpo-Dong, Youngtong-Gu, Suwon-City,
Kyunggi-Do, Korea (16681)

Tel: + 82 (0)31 695 5543

Fax: + 82 (0)31 695 5545

E-Mail

jhchoi35@ophit.com

Regional Office

USA

Foreseeson Custom Display

2210E, Winston Road Anaheim,
CA 92806 USA

Tel: +1-714 300 0540

Fax : +1-714 300 0546

E-mail: jhan@foreseesonusa.com

UK

Foreseeson UK Ltd

Unit 71 Barwell Business Park, Leatherhead road,
Chessington, Surrey, KT9 2NY UK

Tel : +44 (0) 203 588 1607

Fax : +44 (0) 208 546 3931

E-mail: leon.bang@fsnmed.eu

Europe

Foreseeson GmbH

Industriestrasse 38a
63150 Heusenstamm, Germany

TEL: +49(0)6104-643980

FAX: +49(0)6104-64398-11

E-mail: christian.elfert@fsnmed.eu

www.ophit.com



Check your package

Check the package and make sure you have everything:

Contents

- (1) FTSM Transmitter & Receiver
- (2) +5V DC Power supply x 2pcs
- (3) User's Guide

If any of these items are missing in your package, contact OPHIT or your supplier for support.

NOTE: Package content may differ if you have placed a special order or placed order from anywhere other than OPHIT CO., LTD. OPHIT CO., LTD. reserves the right to make changes without further notice to a product described herein to improve reliability, design, packaging or function.

Installation

Installation Steps:

1. Connect the Transmitter module to the SDI source device. (1 x SDI)
2. Connect the Receiver module to the display. (1 x SDI)
3. Connect a single strand of Single-mode LC terminated fiber optic cable(9/125 μ m) from the Transmitter to the Receiver module.
4. Connect the included +5V DC power supply into Transmitter and Receiver module.
5. Blue Active LED indicator on the modules will be light up after all connections are completed.



Check your package

Check the package and make sure you have everything:

Contents

- (1) FTSM Transmitter & Receiver
- (2) +5V DC Power supply x 2pcs
- (3) User's Guide

If any of these items are missing in your package, contact OPHIT or your supplier for support.

NOTE: Package content may differ if you have placed a special order or placed order from anywhere other than OPHIT CO., LTD. OPHIT CO., LTD. reserves the right to make changes without further notice to a product described herein to improve reliability, design, packaging or function.

Installation

Installation Steps:

1. Connect the Transmitter module to the SDI source device. (1 x SDI)
2. Connect the Receiver module to the display. (1 x SDI)
3. Connect a single strand of Single-mode LC terminated fiber optic cable(9/125 μ m) from the Transmitter to the Receiver module.
4. Connect the included +5V DC power supply into Transmitter and Receiver module.
5. Blue Active LED indicator on the modules will be light up after all connections are completed.



Warranty

We, OPHIT hereby warrant the final purchase of our product as follows.
In the case of troubles on our products, please contact the shop purchased.

One year limited warranty

Our customers have right to be served with free of charge when there is trouble in this product during 1(one) year from the day purchased.

Out of warranty services

When you request services (in the case of non manufacturing defects but the troubles by misuse), may served with charge as follows.

- Defects of products caused by accident, disaster.
- Damages of products caused by the customer's carelessness or mistaken application.
- Damages of products caused by the application of the parts or products not supplied or sold by our company.
- Damages of products and related defects caused by not our staff or the men or group not nominated by us for services.

The interchanged parts and products for maintenance services shall be replaced as new parts and products operating normally, and the inter-changed parts and products shall be subjected to our company.

Warranty

We, OPHIT hereby warrant the final purchase of our product as follows.
In the case of troubles on our products, please contact the shop purchased.

One year limited warranty

Our customers have right to be served with free of charge when there is trouble in this product during 1(one) year from the day purchased.

Out of warranty services

When you request services (in the case of non manufacturing defects but the troubles by misuse), may served with charge as follows.

- Defects of products caused by accident, disaster.
- Damages of products caused by the customer's carelessness or mistaken application.
- Damages of products caused by the application of the parts or products not supplied or sold by our company.
- Damages of products and related defects caused by not our staff or the men or group not nominated by us for services.

The interchanged parts and products for maintenance services shall be replaced as new parts and products operating normally, and the inter-changed parts and products shall be subjected to our company.