
FVT/FVR107



Mechanical Installation Instructions

Figure 1: Dimensions are for a standard ComNet[™] one slot module.



Installation Considerations

This fiber-optic link is supplied as a Standalone/Rack module.
Units should be installed in dry locations protected from extremes of temperature and humidity.

Standalone Module:

The unit is provided with a mounting plate with holes for two No. 6 pan head screws (3-mm or 3.55-mm).

Attach the module to a solid piece of wood using two No. 6 pan head wood screws with a minimum penetration into the wood of 3/4 inch. (Screws not supplied)

See figure 1.

- 1. Determine where the module will be installed, and ensure that there is adequate space at both ends for making the various cable connections and for reading the diagnostic LEDs.
- 2. Attach the module to a flat surface using two mounting screws.

Rack Module:

The unit is designed to be installed in the ComNet 19-inch (483-mm) EIA standard card-cage rack, the C1-US, C1-EU, or the C1-CH. Follow these guidelines to install rack cards after performing module setup procedures.

C1-US, C1-EU, or the C1-CH Card Cage Racks

CAUTION: Although the units are hot-swappable and may be installed without turning power off to the rack, ComNet recommends that the power supply be turned off and that the rack power supply is disconnected from any power source. **Note:** Remove electrical connector before installing in card cage rack.

1. Make sure that the card is oriented right side up, and slide it into the card guides in the rack until the edge connector at the back of the card seats in the corresponding slot in the rack's connector panel. Seating may require thumb pressure on the top and bottom of the card's front panel.

CAUTION: Take care not to press on any of the LEDs.

2. Tighten the two thumb screws on the card until the front panel of the card is seated against the front of the rack.



INSTALLATION INSTRUCTIONS

10-BIT DIGITAL VIDEO WITH 1 BI-DIRECTIONAL DATA CHANNEL/DUAL OPTICAL PORT REDUNDANT POINT-TO-POINT CONFIGURATION + 8 CONTACT CLOSURES

Communication Networks

3 Corporate Drive • Danbury, CT 06810 • USA Tel: 203-796-5300 • Toll Free: 1-888-678-9427

www.comnet.net

MULTIMODE OR SINGLE MODE **OPTICAL FIBER** FVT107 SMM REDUNDANT VIDEO TRANSMITTER BI-DIRECTIONAL DATA 8 CHANNEL OB 64 07 <-ON 06 田田 05 www.comnet.net 203-796-5300 04 **OLINK B** 03 O VIDEO DOUT 02 O DATA 0.1 OPOWER CONTACT BLACK WITH WHITE STRIPE -BLACK •

NOTE: Remove Electrical Connector for **Rack Mount Units**

WARNING: Unit is to be used with a Listed Class 2 or LPS power supply rated 9-12 VDC @ 1A.

WARNING: This unit should be installed in a restricted access location; available through the use of a lock and key or other means of security. Access should be limited to service personnel who have been instructed about the reasons for the restrictions to the location. Any and all precautions should be taken and controlled by the authority responsible for the location.

IMPORTANT SAFEGUARDS:

A) Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.

INS_FVTFVR107_REVA



INSTALLATION INSTRUCTIONS

10-BIT DIGITAL VIDEO WITH 1 BI-DIRECTIONAL DATA CHANNEL/DUAL OPTICAL PORT REDUNDANT POINT-TO-POINT CONFIGURATION + 8 CONTACT CLOSURES

MULTIMODE

OR SINGLE MODE

Communication Networks

3 Corporate Drive • Danbury, CT 06810 • USA Tel: 203-796-5300 • Toll Free: 1-888-678-9427 www.comnet.net

OPTICAL FIBER FVR107 SM REDUNDANT VIDEO RECEIVER BI-DIRECTIONAL DATA 8 CHANNEL CONTACT CLOSURE OB 0.7 0 6 05 www.comnet.net OLINKA 203-796-5300 0.4 O LINK B 03 O VIDEO 02 CIDATA 01 O POWER CONTACT BLACK WITH WHITE STRIPE =

NOTE: Remove Electrical Connector for Rack Mount Units

WARNING: Unit is to be used with a Listed Class 2 or LPS power supply rated 9-12 VDC @ 1A.

WARNING: This unit should be installed in a restricted access location; available through the use of a lock and key or other means of security. Access should be limited to service personnel who have been instructed about the reasons for the restrictions to the location. Any and all precautions should be taken and controlled by the authority responsible for the location.

IMPORTANT SAFEGUARDS:

A) Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.

INS_FVTFVR107_REVA




INSTALLATION INSTRUCTIONS

10-BIT DIGITAL VIDEO WITH 1 BI-DIRECTIONAL DATA CHANNEL/DUAL OPTICAL PORT REDUNDANT POINT-TO-POINT CONFIGURATION +8 CONTACT CLOSURES

Communication Networks

3 Corporate Drive • Danbury, CT 06810 • USA Tel: 203-796-5300 • Toll Free: 1-888-678-9427

www.comnet.net




LED INDICATORS

	OPTIC	VIDEO	POWER
GREEN	Communication link has	An active video signal is	Unit powered up
	been established over	present on the BNC	
	optical fiber	connector.	
RED	Communication link has	No video signal	_
	not been established.		
0FF	Not powered up correctly	_	Unit powered down



10-BIT DIGITAL VIDEO WITH 1 BI-DIRECTIONAL DATA CHANNEL/DUAL OPTICAL PORT REDUNDANT POINT-TO-POINT CONFIGURATION + 8 CONTACT CLOSURES




SWITCH POSITIONS FIG. A


RS-232 DATA

1 2
ON ON ON







RS-485, 2-WIRE SENSORNET DATA



RS-485, 4-WIRE DATA




LINK A, LINK B RELAY OUTPUTS:



Terminal pairs are closed when the corresponding Optical Port has established LINK.

Terminal pairs are open when the corresponding Optical Port has lost LINK.

ALARM RELAY OUTPUT, FVR107 ONLY:




Terminal pair is closed when <u>BOTH</u> Optical Ports have established LINK.

Terminal pair is open when either Optical Port has lost LINK.

INS_FVT107_REVA





^{*} See Fig. A, Page 6 for Switch Settings